



NOTES:

1. Install sprinkler heads at least 150 mm (6") from pavement adjacent to planter areas, and at least 100 mm (4") from paving in lawn areas.
2. Use teflon tape on all threaded fittings.

Dimensions are in millimeters, except as noted

| | | | |
|--|---|---|------------------------|
| REVISIONS NO. DATE | | CITY OF LONG BEACH, CALIFORNIA DEPARTMENT OF PUBLIC WORKS | STANDARD PLAN NO. |
| 1 12/23/02 2 3 4 | SPRINKLER HEAD INSTALLATION TYPE B | | METRIC 408 |
| APPROVED BY: <i>Mark [Signature]</i> CITY ENGINEER R.E. No. 40599 | | DATE: 1/10/03 EX. DATE 03/31/03 | SHEET 1 OF 1 |